

InTemp[®] CX5000

InTemp CX Gateway (CX5000)

The CX Gateway links your InTemp data loggers seamlessly to the InTempConnect cloud-based data platform to provide real-time alert notifications for InTemp loggers automatically. Just place the Gateway within a 100-foot range of one or more loggers and connect it to your local Wi-Fi or Ethernet. If an excursion occurs, alerts can be sent from InTempConnect via email and text to a user-defined group of administrators.

In addition to flexible alarm notification capabilities, the CX Gateway can automate the process of downloading data from one or more InTemp loggers within range. It can automatically download loggers at fixed intervals – daily, weekly or monthly – or upon arrival of shipments. This saves time and eliminates the need to remove loggers to download them. No more missed downloads of temperature data for your critical temperature-sensitive shipments.

Included Items:

Mounting Kit AC adapter

Required Items:

InTempConnect account InTemp app BLE-enabled device
with iOS or Android CX series loggers



InTemp CX5000 Specifications

Transmission Range	Approximately 30.5 m (100 ft) line-of-sight
Wireless Data Standard	Bluetooth 4.2 (BLE)
Connectivity	WiFi 802.11a/b/g/n 2.4/5 GHz or 10/100 Ethernet
Power Source	AC adapter
Dimensions	12.4 x 12.4 x 2.87 cm (4.88 x 4.88 x 1.13 inches)
Weight	137 g (4.83 oz)
	The CE Marking identifies this product as complying with all relevant directives in the European Union (EU).

Contact Us

Sales (8am to 5pm ET, Monday through Friday)

- ▶ Email sales@onsetcomp.com
- ▶ Call 1-508-759-9500
- ▶ In U.S. toll free 1-800-564-4377
- ▶ Fax 1-508-759-9100

Technical Support (8am to 8pm ET, Monday through Friday)

- ▶ Contact Product Support www.onsetcomp.com/support/contact
- ▶ Call 1-508-759-9500
- ▶ In U.S. toll free 1-877-564-4377

Onset Computer Corporation
470 MacArthur Boulevard
Bourne, MA 02532